



**NOTES:**

1. INSTALL TEST BOX AS SHOWN ON DWG W-39 AND W-42.
2. CONTRACTOR TO PLACE ALL CONNECTION HARDWARE (SHUNTS AND SPLIT BOLTS) IN TEST BOX, BUT MAKE UP TEST LEAD-TO-SHUNT CONNECTION ONLY. ATTACH SPLIT BOLT TO OTHER END OF SHUNT, BUT LEAVE ANODE LEAD OPEN. FINAL CONNECTION TO BE MADE AT SYSTEM ACTIVATION.
3. ANODE LEADS ARE NOT TAGGED.

<p>APPROVED: <i>Wally P. [Signature]</i> 5/16/19 District Engineer Date 5/16/2019 Latest Revision Date</p>	<p style="text-align: center;">               VALLEY CENTER MUNICIPAL WATER DISTRICT              STANDARD DRAWING  <b>SINGLE ANODE              TEST STATION WIRING</b> </p>	<p>NOT TO SCALE DWG. NUMBER <b>W-51</b></p>
--	--	---