



**NOTES:**

1. PROVIDE 18" SLACK WIRE AT WELD AND COILED IN TEST BOX.
2. WIRE TRENCH SHALL BE 24" DEEP MIN. PLACE 3" OF SAND OR D.G. BEDDING IN TRENCH BEFORE PLACING WIRES. COVER WIRES WITH 6" OF SAND OR D.G. COMPACT WIRE TRENCH FILL PER VCMWD STANDARD.
3. USE 6" WIDE, 4 MIL THICK INERT PLASTIC TAPE PRINTED WITH "CAUTION: CATHODIC PROTECTION CABLE BELOW". PLACE 12" BELOW GRADE.
4. TEST BOX TO BE PLACED BEHIND CURB IN SIDEWALK, BEYOND EDGE OF SIDEWALK, OR IN PLANTER AS SHOWN PER ENGINEER'S DIRECTION. IF NO CURB EXISTS, LOCATE TEST BOX JUST OFF PAVED SURFACE. IN UNPAVED AREAS OR PARKING LOTS, LOCATE TEST BOX OVER PIPE BUT NOT DIRECTLY IN PARKING SPACE. (SEE DWG W-40)

<p>APPROVED:            District Engineer      Date          5/16/2019          Latest Revision Date</p>	<p style="text-align: center;">          VALLEY CENTER MUNICIPAL WATER DISTRICT          STANDARD DRAWING  <b>2 - WIRE TEST STATION          (PAVED STREET)</b> </p>	<p style="text-align: center;">         NOT TO SCALE          DWG. NUMBER  <b>W-39</b> </p>
--	---	---